

VHF Channel list for TP9000 EX Radio

Channel position	VHF Channel Number	Frequency MHz	Simplex
1	6	156.300	Intership
2	8	156.400	Intership
3	9	156.450	Intership
4	10	156.500	Intership
5	11	156.550	Port
6	12	156.600	Port
7	13	156.650	Intership/Port
8	14	156.700	Port
9	15	156.750	Intership/Port
10	16	156.800	Distress and calling
11	17	156.850	Intership/Port
12	67	156.375	Intership
13	68	156.425	Port
14	69	156.475	Intership/Port
15	74	156.725	Port
16	77	156.875	Intership

UHF Channel list for TP9000EX Radio

Single frequencies for simplex channels

Channel position	Frequency	CH Spacing
1	457.525 MHz	25KHz
2	457.550 MHz	25KHz
3	457.575 MHz	25KHz
4	467.525 MHz	25KHz
5	467.550 MHz	25KHz
6	467.575 MHz	25KHz

Additional channels for 12,5 KHz equipment

Channel position	Frequency	CH Spacing
7	457,5375 MHz	12,5 KHz
8	457,5625 MHz	12,5 KHz
9	467,5375 MHz	12,5 KHz
10	467,5625 MHz	12,5 KHz

Two-frequency simplex channels for use with repeater only

Channel position	Repeater RX Frequency	Repeater TX Frequency	CH Spacing
11	467.525 MHz	457.525 MHz	25 KHz
12	467.550 MHz	457.550 MHz	25 KHz
13	467.575 MHz	457.575 MHz	25 KHz
14	467.5375 MHz	457.5375 MHz	12,5 KHz
15	467.5625 MHz	457.5625 MHz	12,5 KHz
16			